



維他蒸餾水機清洗程序教學

Vita Water Dispenser Rinsing Procedure



STEP 1



關上熱水掣
Switch off the hot water button

STEP 2



關上凍水掣
Switch off the cold water button

STEP 3



拔掉插頭及靜待2小時
Unplug and wait for 2 hours

STEP 4




2小時後按凍水掣將凍水全部排出
Press the cold water button to release all cold water after 2 hours

STEP 5



再按熱水掣將熱水全部排出
Press the hot water button to release all hot water

STEP 6



將位於水機背後的排水口蓋扭開
Open the lid of drainage at the rear of dispenser

STEP 7




再把排水口內的藍色保險蓋拔出
Pull out the blue rubber cover inside

STEP 8



把水缸內的熱水全部排出
Drain all the hot water out in the water tank

STEP 9



待水缸內熱水全部排出後，蓋回保險制及排水口蓋
Put back the rubber cover and close the lid when the water tank is emptied





維他蒸餾水機清洗程序教學

Vita Water Dispenser Rinsing Procedure



STEP 10




連接水機電源
Plug the water dispenser

STEP 11



開啟凍水掣
Switch on the cold water button

STEP 12



開啟熱水掣
Switch on the hot water button

維他蒸餾水機自行清洗完成
Water Dispenser Rinsing Procedures Completed

